

## **CONNECTIONS WITH DB4020-BOX ENCLOSURE**

You must adapt the DB4020-BOX connector to microphone wires. You can use any combination of cables. There is no standardized wiring planned. The connector has 5 ways. But only 4 ways are used (included the microphone built-in speaker).

Wires (Baofeng mic): **Green:** SPEAKER or GND (disassemble the microphone to see the color of the cables inside) **Red:** MIC **White:** GND or SPEAKER (disassemble the microphone to see the color of the cables inside) **Black:** PTT






Notes:

• See also the DB4020 / EGV+ BOX manual.


• Some sets of microphones may have different wiring. In case of doubt, it is recommended to disassemble the microphone to see the color of the cables inside.



## **GENERAL USE FOR OTHER CABINETS**

## **Electret microphone / Speaker.**

## Microphone inside:




Wiring jacks to radio are:



Socket jacks board kit.

Before mounting the external connection jacks, you should cut the protrusions located at the bottom of these jacks; otherwise you will not be able to solder them in the correct position. See the image.





2.5 and 3.5mm jacks socket board